

This Bluetooth Converter enables you to connect any cellular phone that supports Bluetooth capability to standard telephones and telephone equipment.

Items required for setup:

- Bluetooth Converter Box (BTC)
- Phone cable
- Power supply
- Standard telephone (not included)
- Bluetooth Cellular Phone (not included)

Follow the step by step instructions to begin using your Bluetooth Converter.

1. Plug phone
2. Plug power
3. Pair
4. Call

Diagram

## PLUG PHONE

1. Use the enclosed phone cable to connect a standard telephone to the "PHONE" connector

DO NOT connect the standard telephone into the "IN- HOUSE WIRE" connector.




## PLUG POWER

1. Plug the power supply module into a 110 volt power receptacle.



2. Plug the power cord from the power module into the Bluetooth Converter box. "Power" light will turn on, then "Wireless Communication" light will turn on to indicate the Bluetooth connection has been established. Wait until the flashing "Line" light stops before using any instrument.



## PAIR

PAIRING THE BLUETOOTH CAPABLE CELLULAR PHONE TO THE CONVERTER

1. Turn on the cellular phone with the Bluetooth connection and the cellular phone must be in the Discoverable Mode. Only the cellular phone to be paired should be in the area. All other cellular phones with bluetooth capability should be turned off.
2. From the Phone connected to the "Phone" connector, press \*\*1, then enter any four number passcode.
3. Press "OK" to accept the pairing and the cellular phone will ask for the passcode.
4. Enter the four number passcode. The cellular phone should indicate that the pairing was successful. Hang up the Phone and the cellular phone should connect and the "WIRELESS COMMUNICATION" light on the Converter should be on. The cellular phone display will ask if you wish to connect.
5. If the pairing procedure is not successful within two minutes, hang up and try again by repeating the above procedure.
6. If the sound is not active after the cellular phone is paired and the wireless communication light is lit, press \*\*8 on the Internal Phone.

## CALL

You can now use the standard telephone to call out over the cellular phone or to answer an incoming call from the cellular phone. To dial out, go off hook, dial the number and then press the "#" key.

For more detailed instructions and features, please refer to the Bluetooth Converter Manual.